

CEN F-450 Ultimate Hitch Kit

If you need further assistance with this hitch installation, please check out our install guide on Youtube by searching:

“QCRC CEN F-450 Ultimate Hitch Kit Installation Guide”

For this installation you will need:

- 2.0mm Hex Driver
- 2.5mm Hex Driver
- 5.5mm Nut Driver
- Blue Loctite (Recommended)

While these parts are strong together as one, they can be weak by themselves. Please use caution when tightening down the parts, as you can easily overtighten and damage the parts.

Installation

1. Begin by removing the four 2.0mm screws on the factory frame mount.
2. Part A: Using the supplied 2.5mm screws, 5.5mm nuts, and washers. Install onto each frame rail placing the curved end toward the truck while leaving the smooth side facing outward.
3. Part B: Using the supplied longer 2.5mm screws, install the Hitch Receiver Mount to the extended frame rails, being sure to not overtighten them.
4. Take Part C: and screw in the supplied 2.8mm Ball Stud, being sure to not overtighten.
5. Take Part D: and install into part B by Sliding it in the center and over the desired hole position on part D. Then screw together using the medium sized 2.5mm screw.
6. Now take Part C: and slide over the desired hole position on Part D. Tightening down using a medium sized 2.5mm screw with 5.5mm nut and washer

Congratulations! Installation is now complete and you can begin to tow with confidence!

If for some reason you do break a part, we will be offering individual parts as replacements for sale on our website

<https://qcrchobbies.weebly.com/products.html#/>

Be sure to check out all the other parts we offer!

Thank you for purchasing this QCRC Hobbies product and have an awesome day!