

CEN F-450 Ultimate Servo Kit

If you need further assistance with this kit installation, please check out our install guide on Youtube by searching:

“QCRC CEN F-450 Ultimate Servo Kit Installation Guide”

For this installation you will need:

- 2.0mm Hex Driver
- 5.5mm Nut Driver
- Blue Loctite (Recommended)

While these parts are strong together as one, they can be weak by themselves. Please use caution when tightening down the parts, as you can easily overtighten and damage the parts.

Installation

1. Begin by removing the two 2.0mm screws holding the servo to the frame mount.
2. Remove the two 2.0mm screws holding the factory servo mount to the frame
3. Now you will need to cut off the factory servo mount tabs sticking up from the center chassis plate. We highly recommend a Dremel.
4. Now remove the 2.0mm screw holding the axle brace to the frame and set aside for later reinstallation
5. On each side take the longest (M3x20mm) screw and a washer and begin to place from the bottom of the truck through the hole closest to the front of the truck where the old servo mount was removed from.
6. Take your servo mounts and place over top of the screws you just installed ensuring the front is to the front (marked with an F) then place a washer and 5.5mm nut overtop to hold the mount in place leaving loose for now
7. Now take your servo and slide up against the servo mount from the bottom of the truck then take the other two supplied M3x16mm screws and washers. Screw them into the servo mount then the servo from the bottom.

8. Now take a washer and 5.5mm nut and install over the two previously installed screws
9. Now you may begin to tighten everything down snug being sure to not overtighten

Congratulations! Installation is now complete and you can begin to steer with confidence and reliability!

Be sure to check out all the other parts we offer on our website!
<https://www.qcrchobbies.com/#/>

Thank you for purchasing this QCRC Hobbies product and have an awesome day!